


We bring DV

 **CyberHome**


***Digital
Video
Recorder***




Operation Guide

CH-DVR 1500

SAFETY INSTRUCTIONS



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL FOR SERVICING.

Explanation of warning symbols



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of not isolated dangerous voltage within the inside of the product that may be sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and servicing instructions in the literature accompanying the appliance.

Read the following instructions carefully

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR ANNOYING INTERFERENCE, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE AND ONLY USE THE RECOMMENDED ACCESSORIES.

- Read these instructions - When using this unit, basic precautions outlined in this section should always be followed.
- Keep these instructions - Retain this user manual for future reference.
- Heed all warnings - Follow all warning labels on the product, and the safety instructions in this manual.
- Follow all instructions - Adhere to the instructions outlined in this manual and on the unit.
- Clean only with a dry cloth - Unplug the unit before cleaning. Do not use any liquid or detergents for cleaning.
- Do not block any ventilation opening. Install in accordance with the manufacture's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defect the safety purpose of the polarized plug. A polarized plug has two blades with one wider than the other. The wide blade is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments / accessories specified by the manufacturer.
- The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug is damaged, liquid has been spilled, objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, or when the unit does not operate normally, or has been dropped.
- Power cord protection - To avoid any malfunctions of the unit and to protect against electric shock, fire or personal injury, please observe the following:
 - a) Hold the plug firmly when connecting or disconnecting the AC power cord to this unit.
 - b) Do not connect or disconnect the AC power cord with wet hands.
 - c) Keep the AC power cord away from heating appliances.
 - d) Never put any heavy object on the AC power cord.
 - e) Do not attempt to repair or reconstruct the AC power cord in any way.
- Remove dust, dirt, etc. on the plug at regular intervals.
- If the unit has been dropped or otherwise damaged, turn off the power and disconnect the AC power cord.
- If smoke, odors or noises are emitted from the unit, turn off the power and disconnect the AC power cord.
- Placement - Avoid placing the unit in areas of direct sunlight, heating radiators, closed automobiles, high temperature (over 35° C (95° F)), high humidity (over 90%), excessive dust, vibration, impact or where the surface is tilted, as the internal parts may be seriously damaged.
- Non-use periods - When the unit is not used, turn the power off.
- When the unit is unused for a long period of time, the unit should be unplugged from the household AC outlet.
- No fingers or other objects inside - Touching internal parts of this unit is dangerous and may cause serious damage to the unit. Do not attempt to disassemble the unit.
- Do not put any foreign object on the disc tray.
- Keep away from water and magnets.
- Keep the unit away from flower vases, tubs, sinks, etc. If liquids are spilled into the unit, serious damage could occur.
- Keep magnetic objects, such as speakers, distant from the player.
- Stacking - Place the unit in a horizontal position and do not place anything heavy on it.
- Do not place the unit on amplifiers or other equipment which may become hot.
- Condensation - Moisture may form on the lens in the following cases: a) immediately after a heater has been turned on b) in a steamy or very humid room c) the unit is moved from a cold environment to a warm one.
- If moisture forms inside this unit, it may not operate properly. In this case, turn off the power and wait about one hour for the moisture to evaporate.
- Noise interference while a broadcast is being received - depending on the reception condition of the TV, interference may appear on the TV screen while you are watching a TV broadcast, if the unit is switched on. This is not a malfunction of the unit or the TV. To watch a TV broadcast, turn off this unit.
- Caution - Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.



SAVE THESE INSTRUCTIONS

CONTENTS

INTRODUCTION

Features	4
Optical disc compatibility	5
Caring for optical discs	5

GETTING STARTED

Checking the package contents	6
Installing batteries in the remote control	6
Using the remote control	6

FUNCTIONAL OVERVIEW

Remote control functions	7
Front panel functions	8
Front VFD display	9
Back panel connections	10

CONNECTIONS

Video connection to TV	11-12
Audio output connections	13
Antenna connections	13
A/V input connections	14

OPERATION OVERVIEW

Powering on the unit	15
Initial Setup	15

PLAYBACK

Selecting the DVD function	16
Using disc menus	16
Basic disc playback	17
Advanced disc playback	18
Using the ZOOM feature	19
Multi-angle function	19
Using subtitles	20
Changing the audio track	20
Displaying playback information	20
Viewing JPG files	21
Playing MP3	22

RECORDING

Intro to recording	23
Setting recording options	24
Setting the Time and Date	24
TV Tuner Setup	25
The Title Navigator screen	26
Types of Recordings	26
Making a Live Recording	26

Timer Recording	28
-----------------------	----

EDITING YOUR RECORDINGS

The EDIT menu	30
Erasing a Title	30
Play Full Title	30
Make Compatible	30
Finalize	30
Edit Title	31
Inserting Chapter Markers	31
Deleting Chapter Markers	32
Hiding Chapters	32
The HIDE Button	33
Show Chapters	33
New Picture	34
Erasing a DVD+RW disc	34

THE DVD RECORDER SETUP MENU

Using the Setup Menu	35
Language Settings	35
Video Setup	36
Audio Setup	36
System Setup	37
Disc Media Options	38
Record Mode Options	38
Timer Record	38

TROUBLESHOOTING

Playback	39
Recording	39

SPECIFICATIONS


.....	40
-------	----

INDEX

.....	41
-------	----

INTRODUCTION

CH-DVR 1500 Personal DVD+R/RW Recorder and Progressive Scan Player



The CH-DVR 1500 is a DVD Recorder/Player with Progressive Scan Video Output. DVD+R/RW Recording gives you the ability to create your own DVD discs from your home movies, favorite TV programs and more. Because of the outstanding compatibility of DVD+R/RW discs, the discs you create will be suitable for playback in most DVD players. You can record from the unit's built-in TV Tuner or an external video source like a video camera. And when you're ready to watch your recordings or commercial DVDs, you can enjoy them in the highest quality with the unit's Progressive Scan Video Out and Digital Audio Out.

DVD+R/RW Recorder

- Live, Timer and Scheduled Recording Functions
- Multiple Recording Modes, HQ, SP, LP, EP, SLP
- Up to 6 Hours Recording on one DVD+R/RW Disc
- On-Screen Disc Title Navigator gives you quick, easy access to your Recordings
- Built-In TV Tuner, Front and Rear A/V Inputs
- Editing features with Auto, Add/Del, Hide Chapters
- Your recordings are playable on most DVD Players

Progressive Scan DVD Player

- Progressive Scan Video with 3:2 pulldown
- Plays DVD, VCD/SVCD, CD-ROM, MP3, JPG and other disc types
- Component Video, S-Video and Composite Video Outputs
- 96 kHz / 24 bit D/A converter
- Stereo Audio out, Optical and Coaxial digital outputs.
- Advanced playback functions: Slow playback, repeat playback, parental control, MP3 player, JPG player, screen saver, Zoom In/Out, track selection, on-screen display and more

Optical disc compatibility

This unit is compatible with a wide range of available optical discs for recording and playback.

Discs suitable for Recording and Playback

You must use DVD+R or DVD+RW discs to record on this unit.

DVD+R: These discs can only be written to once. Existing recordings can be hidden but not deleted. So, any disc space already used by a recording cannot be regained. DVD+R discs are required to be "Finalized" before they will be compatible with standard DVD Players. Once a disc is finalized, no further recordings can be made.

DVD+RW: DVD+RW discs can be written to and erased multiple times. Existing recordings can be deleted and disc space regained. These discs do not require a finalization procedure. As soon as a recording is made, the disc will be compatible with standard DVD Players.



Discs suitable for Playback Only

DVD Video: This unit plays DVDs recorded for a particular region. The region mark on the back of the player must correspond to that on any DVD discs you wish to play. Units sold in North America are coded for Region 1, and are compatible with discs marked accordingly.



DVD-R/RW: These discs can be played back when recorded in standard DVD Video format.



DVD-Audio: This unit will playback only the 5.1CH sound track on DVD-Audio discs.



CD-Audio: An on-screen navigator is provided to select and play tracks when using CD-Audio discs.



Video CD - VCD/SVCD: On VCD/SVCD discs, advanced features such as PBC (Playback Control) are available.




CD-R/RW: This unit features an on-screen navigator for easy access to playable files stored on CD-R/RW discs, such as JPG images and MP3 music.



Caring for Optical Discs

- Hold a disc by the rim or with an index finger in the central hole. Never touch the signal surface.
- Finger prints or stains on the surface of the disc may cause signal loss.
- Use a soft cloth and wipe in a radiating manner from the center of the disc to the outer rims when cleaning the disc surface.
- Never add labels or adhesive tapes on the discs and be careful not to scratch or damage the disc surface.
- To prevent discs from becoming bent or deformed, they should be vertically kept in the disc storage case. To prevent damage, avoid leaving discs in your car, where they may be subject to direct sunlight and high temperature.
- Do not use any disc accessory to improve the audio quality, disc protective solutions or lens cleaner. These products may damage the disc surface.




Make sure the package contents are complete

In addition to the DVD/Receiver, your package should contain the following accessories. Check the contents of the package carefully, as some items may be located under the packing foam.


Remote control




Batteries (2) AAA




Power cord




RF Cable for TV




A/V cable (Composite Video, Stereo Audio)




This operation manual and warranty card



Blank DVD+RW Discs (3) & Disc Holder



***Optional Splitter for units without Antenna Passthrough Connector (See page 13)**




Installing batteries in the remote control

This unit comes complete with batteries for the remote control. When installing batteries, be sure to take note of the polarity markings on the inside of the battery compartment and match them up with those on the batteries.

1 Slide off the back cover.

2 Install the batteries in the correct orientation as shown to the right and marked on the battery compartment.




Notes on batteries

- If the remote control functions better when it is closer to the unit, the batteries may be running low.
- In case of any leakage of batteries, dispose of the batteries right away and avoid touching the chemical discharge. Make sure to clean the remote control's battery compartment before installing new batteries.
- Do not mix batteries of different types, or use old batteries with new ones.


Operating the remote control

When using the remote control, be sure to stay within a 30 degree angle of the sensor on the receiver. Keep in mind that any obstructions between the remote control and the receiver will effect performance.




FUNCTIONAL OVERVIEW

Remote Control




- 1 **STANDBY** - Turns the unit on and sends the unit to Standby mode.
- 2 **MENU / PBC** - Accesses Menus on DVD Discs. With VCD discs, turns the PBC function On/Off.
- 3 **SETUP** - Accesses the on-screen Setup Menu for settings adjustment.
- 4 **DISPLAY** - Brings up the on-screen display showing information for the playback session.
- 5 **AUDIO** - Selects an audio track on DVD or VCD discs.
- 6 **SUBTITLE** - Selects available subtitles on DVD discs.
- 7 **ARROW KEYS (CH+/-)** - Use to navigate disc menus, on-screen setup menu, etc. In TV tuner mode, use UP/DOWN to select a channel.
- 8 **FF/FR** - Scan in fast forward or reverse on DVD and other discs.
- 9 **NEXT/PREVIOUS** - Advanced to the next track or plays previous track on DVD and other disc.
- 10 **PAUSE** - Use to Temporarily stop play.
- 11 **NUMBER KEYS** - Use to enter numeric values while setting options.
- 12 **C-SKIP** - Skips ahead in 30 second intervals during playback. This function is intended to assist in skipping over commercials during playback of TV recordings.
- 13 **ZOOM** - Press to magnify the screen with DVD and JPG discs.
- 14 **DVD/TV LIVE** - Switches between Live Recording mode and DVD Player mode.
- 15 **SOURCE** - Selects the input video source for recording. Choices include built-in TV Tuner and AV Inputs.
- 16 **REC** - Press to begin a live recording.
- 17 **REC MODE** - Selects the recording quality mode - HQ, SP, LP, SLP, EP.
- 18 **OPEN / CLOSE** - Opens and closes the disc tray.
- 19 **TITLE** - Accesses the title screen on DVD+R/RW discs, displaying a graphical representation of the recordings and providing easy navigation.
- 20 **BOOKMARK / HIDE** - In DVD Playback mode, use to store specific locations on a disc for quick navigation. When editing recordings sets start and end points for hiding specific sections.
- 21 **DIGEST / ANGLE** - Displays thumbnail images for previewing files on JPG discs. Selects between multiple angles with DVD Discs that support this feature.
- 22 **MUTE** - Temporarily cancels audio playback.
- 23 **ENTER** - Selects options in menus. Plays a disc, chapter or track with some discs. For other discs, press PLAY.
- 24 **PLAY** - Plays a disc, chapter or track.
- 25 **SLOW** - Slow motion playback mode in 1/2, 1/4 or 1/8 speed. Press PLAY to resume normal playback.
- 26 **STOP** - Press once to stop playback and hold the last position in memory. Playback can be resumed where it was left off by pressing PLAY. Press twice to clear the last playback position.
- 27 **CLEAR** - When entering input, use to delete characters.
- 28 **A-B REPEAT** - Sets the beginning and end points of a section to repeat.
- 29 **REPEAT 1/ALL** - Selects a repeat option - Chapter, Title or Disc.
- 30 **TIMER** - Accesses the timer menu for scheduled recording setup.
- 31 **EDIT** - Accesses the edit menu for DVD+R/RW editing options.

Front Panel



- 1 ON / STANDBY** - Turns the unit on and sends the unit to standby mode. The main power switch on the back of the unit must be turned on before using the standby button. In standby mode, the unit will use a minute amount of power to enable power-on by the remote control.
- 2 VFD DISPLAY** - The front Vacuum Fluorescent Display shows information about the unit's operation, such as current chapter and elapsed time during playback and disc tray status.
- 3 DISC TRAY** - Loads DVD+R/RW, DVD, CD-ROM, VCD/SVCD, MP3, JPG and other optical discs.
- 4 OPEN/CLOSE** - Press to open or close the disc tray.
- 5 RECORD** - Begins a Live Recording.
- 6 DVD/TV LIVE** - Switches from DVD playback mode to Live Recording Input mode.
- 7 SOURCE** - Selects between available Input Sources when the Recorder is in Live Record mode - TV Tuner, VIDEO IN 1 / 2, S-VIDEO IN 1 / 2.
- 8 PLAY/PAUSE** - Begins playback of a disc, chapter or track. Press again during playback to pause, and again to resume playback.
- 9 PREV/FAST REVERSE** - Press to return to the previous chapter or track. Press and HOLD to scan in reverse mode at 2X (twice normal speed). Press and hold again repeatedly to scan at 4X, 8X, 16X, 30X or 60X speed.
- 10 STOP** - Press once to stop playback of a disc and save the location of the stop point. The disc can be played back from the stop point by pressing PLAY. To erase the stop point and reset the play location to the beginning of the disc, press STOP a second time.
- 11 NEXT/FAST FORWARD** - Press to advance to the next chapter or track. Press and HOLD to scan in reverse mode at 2X, 4X, 8X, 16X, 30X or 60X speed.
- 12 SETUP/TIMER** - Accesses the On-Screen Setup Menu and Timer Schedule screen. Use SETUP to change options and settings for the Recorder. Use the Timer for scheduling recordings that will begin automatically.
- 13 DOWN** - Navigates downward in menus, etc.
- 14 UP** - Navigates upwards in menus, etc.
- 15 ENTER** - Confirms a choice in menus or settings.
- 16 RETURN** - Returns to the previous menu.
- 17 S-VIDEO IN 2** - Front S-Video Input for recording. To select, use the SOURCE key and select S-VIDEO IN 2.
- 18 LEFT/RIGHT AUDIO IN 2** - Front Stereo Audio Inputs for recording. These inputs are shared with the VIDEO IN 2 and S-VIDEO IN 2 inputs.
- 19 COMPOSITE VIDEO IN 2** - Front Composite Video Input for recording. To select, use the SOURCE key and select VIDEO IN 2.

Front VFD Display



1 PLAYBACK INDICATORS

These indicators show the playback status of a DVD, CD or other optical disc - Currently Playing: ►, Paused: 00, Stopped: ■

2 TITLE INDICATOR

Displays the number of the current Title on a DVD disc.

3 CHAPTER / PRESET INDICATOR

Displays the number of the current Chapter or Track on DVDs, Music CDs and other discs.

4 FUNCTION INDICATORS

Indicate the status of advanced disc playback functions:

- 1ALL** Repeat Chapter/Title/Track function is active.
- A-B** Repeat A-B Function is active.
- PBC** PBC (Playback Control) Function is enabled.
- ANGLE** Multi-Angle Mode is active.
- ZOOM** The Zoom function is being used.
- RAND** Tracks are being played in RANDOM order.
- REC** Recording indicator.

5 PROCESSOR INDICATORS

These indicators display the status of the surround sound processors and type of sound track currently active.


- Dolby Digital** The Dolby Digital processor is active.
- DTS** The DTS Digital processor is active.
- PCM** The PCM Digital Stereo processor is active.
- 5.1ch 2ch** Indicates 5.1 Channel or Stereo audio source.
- L/R** The L/R option is active.

6 DISC TYPE INDICATORS

Displays the type of optical disc inserted - DVD, SVCD, VCD, CDDA (Music CD), or MP3.

7 MULTI-FUNCTION DISPLAY

When playing a DVD or other optical disc, displays the elapsed time of the playback session or track. Also displays disc tray status, system messages and more. When the unit is in Standby Mode, displays the system clock.

Back Panel

- 1 ANTENNA IN / OUT** - For Antenna or Cable TV connection. Passthrough connection to TV does not transfer the output signal from the DVD Recorder.
*Some units do not have a Passthrough connector. In this case, use the included splitter (See page 13).
- 2 VIDEO INPUT 1** - Composite Video input for recording. To select this input, use the SOURCE button and choose VIDEO IN 1.
- 3 S-VIDEO INPUT 1** - S-VIDEO input for recording. To select this input, use the SOURCE button and choose S-VIDEO IN 1.
- 4 COMPONENT/PROGRESSIVE SCAN VIDEO OUTPUT** - Use this output with TVs supporting Component Video or Progressive Scan input for best video quality. Select this output in the DVD Recorder's SETUP MENU.
- 5 STEREO AUDIO OUTPUT** - Connect to TVs or other audio equipment supporting Stereo Audio in.
- 6 COAXIAL DIGITAL AUDIO OUTPUT** - Use a special coaxial digital audio connector to send the raw coded digital signal to devices supporting digital decoding.
- 7 OPTICAL DIGITAL AUDIO OUTPUT** - Use to connect to a receiver or other device with 5.1 channel decoders. This output is the coded digital signal.
- 8 POWER CORD SOCKET** - Plug the matching end of the power cord into the unit before connecting the other end to the wall socket.
- 9 MAIN POWER SWITCH** - The main power switch must be set to ON for the unit to function. Make sure all cable connections are complete before switching the main power switch to ON. When the main power switch is turned ON, the unit will enter Standby Mode, where it may be turned on with the remote control or the front power switch.
- 10 STEREO AUDIO INPUTS** - Use with S-VIDEO IN 1 or VIDEO IN 1 for recording.
- 11 S-VIDEO OUTPUT** - Connect to TVs with S-VIDEO in for better picture quality than standard composite video.
- 12 COMPOSITE VIDEO OUTPUT** - Standard Video Output supported by most TVs.

CONNECTIONS

Connecting the video output to your TV


In order to use the DVD Recorder, you'll need to make a video connection to your TV. The capabilities of your TV and the cables you have on hand will determine the connections you can use. There are 3 possible connection types:

- Composite Video - The most widely used connection. This unit includes an A/V cable for Composite Video.
- S-Video - A higher quality connection that requires a special S-Video cable and an S-Video capable TV.
- Component Video - The highest quality video connection. Supported on high-end TVs and requires a special cable.

Composite Video (Typical connection)

This unit ships with a composite video (A/V) cable for connection to TVs with a standard video input as shown below. This is the most widely used type of connection. On most TVs, this connector is colored yellow, and is normally accompanied by stereo audio inputs, colored red and white for stereo channels right and left, respectively.


- 1 First, use the supplied A/V cable to connect to the composite video input on your TV. This is normally a yellow-colored connector that matches the Video output on the back of this unit. If you wish to hear sound through the TV, connect the red and white stereo audio connections as well.



- 2 Turn on the TV and DVD Recorder and select the DVD Playback mode with the remote control.

- 3 On your TV, select the video input. This is normally done by selecting "Video 1" or "Video Input" with the remote control. On some TVs, this is done by selecting a particular channel.

- 4 You should now see the DVD Recorder's splash screen on the TV.




! Important note for older TV models

If your TV does not have a composite video-in jack like that pictured above, you cannot connect this unit directly. If this is so, check to make sure your TV has at least a coaxial connector (used for antenna/cable TV/VCR/etc.) such as that pictured to the right. In this case, you can use a *RF Modulator* to convert this unit's video out to the coaxial connection on your TV. RF Modulators are available at major electronics retailers.




Antenna/cable TV coaxial connector on older TVs



S-Video

This is a higher quality connection than standard composite video, and requires a special S-Video cable not included. The S-Video connector is distinguishable by its 4 pins, as shown below. If your TV has an S-Video input, it's recommended that you use this type of connection for better picture quality.


- 1 First, obtain a special S-Video cable. Connect the S-Video output from the unit to the corresponding input on your TV.



- 2 Turn on the unit and select the DVD mode.

- 3 On your TV, select the S-Video input. This is normally done by selecting "Video 2" or "AV2" with the remote control. On some TVs, this is done by selecting a particular channel.

- 4 You should now see the DVD player's splash screen on the TV.




Component Video


The highest quality video connection, component video requires separate cables for the Y, Pb, Pr signals. To use the progressive scan option on this unit, you'll need to use the component video output. Using the component video output requires these steps:

- 1 First, use the supplied A/V cable to connect to the composite video input on your TV. Select this input.


- 2 Enter the player's Setup Menu by pressing **SETUP** on the remote control.



- 3 Change the VIDEO OUTPUT setting under VIDEO SETUP to COMPONENT. If you are using a Progressive Scan TV, change the OUTPUT FORMAT to PROGRESSIVE.



- 4 Press **SETUP** to exit the **SETUP MENU** and connect the Component Video cables. Select the correct video input on your TV.



! Resetting the video output


If you inadvertently switch the OUTPUT FORMAT setting to PROGRESSIVE while using a standard TV not capable of P-SCAN, you will lose video. If this happens, reset the recorder to its default video settings by following these steps:

- 1) Power the unit Off, then On again with the main power switch on the back.
- 2) Eject the disc and close the disc tray.
- 3) Press and *hold* the STOP button on the front panel for 3 full seconds.

Audio Output Connections


This unit features a variety of audio line outputs for connection to a receiver or other audio equipment.

- Use the included A/V cable to connect the stereo audio outputs for connection to a TV or stereo receiver.
- Optical and Coaxial digital audio outputs send an encoded digital bitstream, suitable for receivers with Dolby or DTS decoding capability. These outputs require special cables not included.




Antenna & TV Connections

This unit is available with and without an *antenna passthrough connection*. For units with only an Antenna input connector, as shown below to the right, use the included Splitter to connect a single RF input signal to the recorder and a TV.




OR




Connecting Audio/Video recording sources to the A/V Inputs

Audio/Video inputs are provided on the front and back of the unit for connection of outside audio/video sources such as VCRs, camcorders, DVD Players, etc. External Video Sources must support S-Video, Composite Video and/or Stereo Audio to be suitable for recording.

Back AV Inputs (VIDEO IN 1, S-VIDEO IN 1)




Front AV Inputs (VIDEO IN 2, S-VIDEO IN 2)




Powering on the unit

Only after all connections are complete, connect the power cord and power on the unit.



- 1 Plug the appropriate end of the power cord into the unit first, then plug the standard jack end into a wall socket or power strip.
- 2 Turn on the main power switch on the back of the unit. The unit is now in **STANDBY MODE**. Once this switch has been turned on, the unit will always be either **ON**, or in **STANDBY MODE**.
- 3 Press **STANDBY** on the remote control or front panel to bring the system out of standby mode. The system is now ready to use.



Notes on power states


There are 3 power states for this unit:

- **OFF** - The main power switch is turned off. The unit draws no power and cannot be turned on by the remote control.
- **STANDBY** - The main power switch has been turned ON, but the unit has not been taken out of standby by pressing either the **STANDBY** key on the remote control or the **ON / STANDBY** button on the front panel. The unit draws a slight amount of power to enable the remote control receiving circuit.
- **ON** - The main power switch has been turned ON, and either the **STANDBY** button on the remote control *or* the **ON / STANDBY** button on the front panel has been pressed. The unit is ready to use.

Initial Setup Procedure

When the unit is first powered on, you'll be prompted to set the time and date as well as TV Tuner options. You can always change any of the settings you choose during the Initial Setup later in the DVD Recorder's **SETUP MENU**.

Using the Menus



- 1 Use the **UP/DOWN** keys to increase or decrease the value of a selected field or move to a field above or below. Use the **LEFT/RIGHT** keys to move to the previous or next fields.
- 2 Press **ENTER** to select an option and/or continue.

Setup Language

You may select English, Spanish or French as the language used by the Initial Setup Menu. When the player's on-screen Setup Menu is accessed later by pressing **SETUP**, this language will be used as well. Press the **UP/DOWN** keys to select a language, then press **ENTER** to confirm.

Choose English Menu
Choose Spanish Menu
Press <ENTER> to continue

Time and Date

Setting the Time and Date correctly is important, since Timer recordings depend on an accurate setting. The Time format used is 24HR. This means that 1:00PM will be represented as 13:00, 2:00PM as 14:00, and so on. Use the **UP/DOWN** keys to increase or decrease the Time or Date and the **LEFT/RIGHT** keys to move to a different field. When you're done, move to **COMPLETED** and press **ENTER**.


Please set the Time and Date
00:05:10
01/01/00
Completed

The Initial Setup is now complete. Remember, any settings chosen during the Initial Setup can be changed at any time in the DVD Recorder's **SETUP MENU**. Press **ENTER** to exit the Initial Setup and begin using your DVD Recorder.

DVD PLAYER OPERATION


Select the DVD Playback Mode

- 1 Press the DVD/TV LIVE button on the remote control or the receiver's front panel to select the DVD mode.




Inserting a Disc

- 1 Press the OPEN/CLOSE button on the remote or front panel to open the disc tray.



- 2 Insert the disc, being careful not to touch the playing surface. Hold the disc by the sides and with your fore finger through the hold in the middle and insert gently into the tray.




- 3 Close the disc tray by pressing OPEN / CLOSE on the remote or front panel.

Using Disc Menus

Playing a Disc from the "ROOT" Menu

Most DVDs will automatically display a menu after the disc is inserted. This first menu is the first of possibly many layers, and is therefore known as the "root" menu.




- 1 Use the ARROW keys on the remote control to navigate through the menu to the appropriate selection to start the movie.
- 2 Press ENTER to confirm your selection.

Accessing a menu after play has started


- 1 If you wish to re-enter the menu after disc play has started, use the MENU key. MENU also exits the menu at any time.

With VCD discs, this button functions as PBC (Playback Control), enabling or disabling the PBC function.




Using the RETURN Key

- 1 Use the RETURN key to go back to the previous layer of a menu. This function can be quite handy when using menus with many layers.



Basic Disc Playback


Starting, Pausing and Stopping Disc Play



- 1** **PLAY** - To begin playback of a disc, press **PLAY/PAUSE**.
- 2** **PAUSE** - To freeze the video on a single frame, press the **PLAY/PAUSE** (Front Panel) or **PAUSE** (Remote Control) key during playback. To resume normal playback, press **PLAY/PAUSE** (Front Panel) or **PLAY** (Remote Control).
- 3** **STOP** - To stop playback of a disc, press **STOP**. The first time **STOP** is pressed the location where disc play was halted is saved, and you can begin playback where you left off by pressing **PLAY**. If **STOP** is pressed twice, the playback location is reset to the beginning of the disc.

Fast Forward and Fast Reverse


You can scan through DVDs, VCDs and other discs in forward or reverse direction at speeds up to 60X (sixty times normal speed). Fast forward/reverse scanning will only work *during* disc playback, not when the disc is stopped.



- 1** To use the fast forward/reverse function with the remote control, press the **FF** or **FR** key repeatedly to cycle through all speeds in the desired direction. Available speeds are 2X, 4X, 8X, 16X, 30X and 60X. To resume normal playback, press the **PLAY** key.
- 2** On the front panel, note that the **FF** and **NEXT** functions share the same button, and likewise for the **FR** and **PREVIOUS** functions. To begin **FF** or **FR** scanning, press and **HOLD** the corresponding button for 2 SECONDS. Repeat this procedure to cycle through all available speeds, and return to normal playback.

Skipping to the Next or Previous Chapter/Track


You can advance or skip back through the chapters or tracks on DVD discs, Audio CDs and other discs with the **NEXT** and **PREVIOUS** buttons on the remote or front panel.




- 1** **SKIP NEXT** - To advance to the next chapter or track, press the **NEXT** button on the remote control or front panel.
- 2** **SKIP PREVIOUS** - Press the **PREVIOUS** button on the remote control or front panel to skip back to the previous track.

Skipping Ahead 30 Seconds with Commercial Skip

The **C-SKIP** button is useful for skipping over the commercials while viewing TV programs that you have recorded.



- 1** Press the **C-SKIP** button to jump ahead 30 seconds during playback, bypassing commercials.



! About the Screen Saver




When disc playback remains paused for a period of about 10 minutes, the Screen Saver will load, protecting the television from "screen burn", which could occur if an unusually bright image is displayed on-screen for an extended period of time.

The Screen Saver must be enabled in the recorder's **SETUP MENU**.

Advanced Playback

Slow Motion Playback


This unit supports slow motion playback to 1/8 normal speed.



- 1 Press the SLOW MOTION button repeatedly to step through all options for slow playback. With DVDs, you can choose from 1/2, 1/4 or 1/8 speed.

Jumping to a Specific Title, Chapter or Time

Along with displaying playback information, the DISPLAY key also provides a convenient way to navigate DVD, Audio CD and other discs by allowing you to select the Title, Chapter/Track or Time to go to.



- 1 During playback, press the DISPLAY key to bring up the DISPLAY MENU.




- 2 Use the LEFT/RIGHT ARROW keys to select Title, Chapter or Time and press ENTER. In this example we will select Chapter to jump to a chapter on the disc.



- 3 With the UP/DOWN ARROW keys, select the chapter that you wish to go to and then press ENTER.




- 4 To jump to a Time on the disc, use the NUMBER keys to enter the time value, then press ENTER.




Repeating a Disc, Chapter, Title or Track


To repeat a segment of a disc, use the REPEAT 1/ALL key. On DVDs, you can repeat an entire disc, title or chapter. On VCDs, chapter and disc repeat is supported, but PBC must be disabled first (Press the PBC key). Audio CDs also allow repeat of tracks or the entire disc.



- 1 Press REPEAT 1/ALL during disc playback to access the REPEAT MENU and then press ENTER.




- 2 Use the UP/DOWN ARROW keys to select a repeat option and then press ENTER. You can repeat the current chapter, title or the entire disc.



- 3 Press REPEAT 1/ALL again to close the REPEAT MENU.

Repeating a Segment You Define

Unlike the REPEAT 1/ALL key, which allows you to repeat segments already defined on a disc, such as tracks and chapters, the REPEAT A-B key lets you define your own segments to repeat.



- 1 During playback, when you reach the start of the segment you want to repeat, press the REPEAT A-B button. The following icon is displayed on-screen, letting you know that the segment start point has been saved.




- 2 When you reach the end of the segment you want to repeat, press the REPEAT A-B button again. The repeat icon on-screen changes to the following, reporting that the endpoint of the video segment has been saved. The segment will now begin repeating.



- 3 To cancel repeat and resume normal playback, press REPEAT A-B again. The repeat icon disappears from the screen.

Multi-Angle Function


Some DVD discs are recorded with multiple viewing angles for certain scenes. When you are viewing a disc that supports this feature, you can choose among the available angles on the disc with the ANGLE key.




- 1 Most discs with multi-angle will display an indicator, or *angle mark*, that alerts the viewer that multiple angles are available for the current scene. When this mark appears on-screen, press the ANGLE button to select an angle to view.

Using the Zoom Function


Use the zoom function to zoom in or out during disc playback or when a frame is paused on-screen. ZOOM also works when viewing JPG images.



- 1 Press the ZOOM key repeatedly to cycle through all the zoom levels - 2X, 4X or 8X. The ZOOM REFERENCE WINDOW appears in the upper left corner of the screen, indicating the ZOOM level and providing a macro view of the "ZOOMED" portion of the screen in reference to normal viewing.




- 2 You can use the ARROW keys to move around the image. This will display the parts of the image that do not appear on-screen when the image is zoomed in. The reference window shows the position of the magnified portion in relation to the rest of the picture.



- 3 Press the ZOOM key repeatedly to return to normal viewing.


Muting the sound

- 1 Press the **MUTE** button on the remote to temporarily cancel the audio signal at any time. Press **MUTE** again to resume normal audio.



Changing the audio track

Most DVD discs are recorded with multiple audio tracks. These can contain multiple languages and different audio formats, such as 5.1 Channel, 2 Channel and DTS. A director's commentary track - where the director can be heard discussing the movie - is also common on DVDs.



- 1 During playback, press the **AUDIO** button to access the **AUDIO MENU** and press **ENTER**.

1/4 : AC-3, 5.1 Ch. - English


- 2 Use the **UP/DOWN ARROW** keys to select an audio track and press **ENTER** to confirm.

3/4 : DTS, 5.1 Ch. - French

- 3 Press **AUDIO** to exit the **AUDIO MENU**.

Subtitles

Most DVD discs include at least one subtitle track in one language. Subtitles are useful viewing movies in a foreign language or for hearing-impaired viewers.



- 1 During playback, press the **SUBTITLE** button to access the **SUBTITLE MENU** and press **ENTER**.

Subtitles Off

- 2 Use the **UP/DOWN ARROW** keys to select an available language and press **ENTER**.

2/3 : Spanish

- 3 Press **SUBTITLE** to exit the **MENU**.

Displaying Playback Information

When playing a DVD, VCD or Music CD, you can display the current title, chapter/track and elapsed playback time on-screen with the **DISPLAY** key.

- 1 During playback, press **DISPLAY** to view available information. In the example below, the current playback is Title 1, Chapter 8 and the elapsed time is 43 minutes, 23 seconds.

001 008 00:43:23

- 2 To cancel the on-screen display, continue pressing **DISPLAY** until the screen is clear.

Viewing JPG Files


Slide Shows

You can view JPG picture files stored on CD-R/RW discs individually or in slide show mode on your TV. JPG is the standard format for pictures stored on digital cameras, the Internet and many other applications.


When you insert a disc with JPG files, a Slide Show will automatically begin.

Viewing thumbnails of your JPG pictures

Thumbnails are smaller sized versions of your JPG files that allow you to preview many files on a single page.



- 1 During slide show playback, press the DIGEST key at any time to see a thumbnail preview of your JPG files. A maximum of 9 images are shown on each screen.




- 2 Use the PREVIOUS / NEXT keys to navigate to the next or previous screen of thumbnails.
- 3 Use the ARROW KEYS to navigate the thumbnail screen, moving to the image you wish to display.
- 4 Press ENTER to display the file on screen.


Using the zoom function with JPGs

You can zoom in or out on JPG images.

- 1 While the picture is displayed, press the ZOOM key. The zoom status is shown in the upper left of the screen. The starting value is 100% normal size.




- 2 Press the ZOOM key repeatedly to zoom in or out. You can zoom in up to 400%, and out to 25% of the original image size.



Rotating and Flipping JPG Images


While a JPG is displayed, you can rotate the image or flip it horizontally or vertically.

- 1 To rotate an image in the clockwise direction, press the RIGHT ARROW key.



Press the LEFT ARROW to rotate the image counter-clockwise.

- 2 To flip the image horizontally, press the UP ARROW key.



To flip the image vertically, press the DOWN ARROW key.


JPG notes

- JPG files must be stored on discs with the extension "JPG", such as "picture1.jpg", otherwise the files will not be recognized.
- You can have a maximum of 250 files or folders.
- CD-R/RW discs containing JPG files should be in ISO/9660, Mode 1, Closed Session format for best compatibility.


Playing MP3 Files

The MP3 Player

When you insert a disc containing MP3 files, the player will launch the MP3 Player - an on-screen interface for playing MP3 music files.



- 1 TRACK LIST** - A list of the tracks and folders on the disc.
- 2 CURRENT FILE** - The current file begin played.
- 3 PLAYBACK INFO** - Displays the current track number, total tracks on the disc and elapsed playback time.



- 1 Use the UP/DOWN ARROW keys to select a file to play. Alternatively, you can jump to a file directly by using the NUMBER keys to enter the file number, then pressing ENTER.**

MP3 notes

- MP3 files must be stored on discs with the extension “MP3”, such as “song1.mp3”, otherwise the files will not be recognized.
- You can have a maximum of 250 files or folders.
- CD-R/RW discs containing MP3 files should be in ISO/9660, Mode 1, Closed Session format for best compatibility.

RECORDING

Introduction to Recording

You already know that DVD discs provide the highest quality video playback available. Now, with DVD+R/RW recording, you can create your own DVDs from your home movies, favorite TV shows or virtually any other video source.

Recording to DVD+R/RW is easy. The process is similar in many ways to your old VCR, but with many new enhancements. You can record live by simply pressing one button, or set the timer for scheduled recordings. And DVD+RW discs can be erased and used again over and over - more than one thousand times - with your recordings always looking crystal clear. Try that with VHS tapes!

And there's lots of new editing features with DVD+R/RW that give your recordings a flexibility that you never had with VHS. The Title Screen gives you quick access to your recordings with thumbnail images you can change. You can quickly add or delete Titles or Chapters, or simply hide segments that don't make your "final cut".

Best of all, your recordings are TWINWAY COMPATIBLE. This means that the discs you create will play in most standard DVD Players. DVD Recording is truly the next revolution in home video recording.



Discs you can Record To

This unit will accept two disc types for Recording: DVD+RW and DVD+R.



Think of DVD+RW (DVD+ReWritable) discs as the digital equivalent of your old VHS tapes. Like video tape, DVD+RW discs can be recorded to, erased and re-used. But unlike video tape, DVD+RW discs will retain their crystal-clear digital quality even after being erased and re-recorded over 1000 times! And, this superior quality will not degrade with the passage of time like VHS tapes.

Also, unlike DVD+R discs, DVD+RW discs do not require a "Finalization" process for compatibility with standard DVD Players. To understand why this is so, consider the following: In order for your recordings to be compatible with standard DVD Players, a TOC (Table of Contents) must be written to each disc. Since DVD+RW discs are ReWritable, the TOC can be constantly updated as new recordings are made. This means that a DVD+RW disc can be played on a standard DVD Player directly after the first recording, and will remain compatible as new material is added later.

Although DVD+RW discs are more expensive than DVD+Rs, they can actually be more economical and convenient for certain situations. For example, if you are recording TV programs you may want to "recycle" discs - recording over episodes you have already watched. In this situation, DVD+RW discs are the best choice because a single disc can be used over and over again - there's fewer discs to buy and keep track of.



A lower-cost alternative to DVD+RW, these "Recordable" discs cannot be erased. Once a recording is made to a DVD+R disc, the disc space used by that recording can never be reclaimed, although the recording itself can be "hidden" so it is not viewable when the disc is played.

DVD+R discs must be *Finalized* before they can be played back on standard DVD Players, and once this process is complete, no more recordings can be added. This is an important difference between DVD+R and DVD+RW Discs. While the TOC (Table of Contents) can be written to and updated many times on a DVD+RW disc, the TOC on a DVD+R disc can only be written once. Therefore, you cannot move a DVD+R between the Recorder and a DVD Player as you add recordings to the disc. Instead, you must complete the disc *before* it is playable on a standard DVD Player.

Although DVD+R offers less recording flexibility than DVD+RW, the lower cost per disc and the fact that the material cannot be erased or edited make it the best choice for large distributions of recordings to friends or clients.

What you can Record From

You can record your own DVDs from the following sources:

TV Tuner - This unit features a built-in TV Tuner that can be connected to a Cable TV hookup or standard Antenna to record your favorite TV shows. You can auto-scan for available channels and add or delete channels from the channel list.

AV Inputs (Composite/S-Video) - Use the Audio/Video Inputs to record from consumer electronics devices such as your Camcorder or Video Camera. You can also connect external TV Tuners, DVD Players, etc. to the A/V inputs - basically any video device that has a S-Video or Composite Video Output.

! About Copy Protection


You cannot record from a video source that is encoded with Macrovision copy-protection, such as most DVDs produced by major studios. As an example, if you have a DVD player connected to an AV input and attempt to record a DVD, an error message will occur, letting you know that the disc is copy-protected. DVDs not encoded with Macrovision can be used as a recording source.

Setting Recording Options


There are several recording options and other settings that should be understood and checked before you begin recording.

Setting the Record Speed


The Record Speed determines the quality of your recordings as well as the maximum amount of video you can record on a disc. Not surprisingly, the higher the quality, the less video can be recorded.



- 1 Press **SETUP** to enter the **SETUP MENU**. Press the **DOWN** key repeatedly to select the **RECORD MODE** menu and press **ENTER**.



- 2 Press **ENTER** to select the **Record Speed** menu. Select a **Record Speed** with the **UP/DOWN** keys and confirm with **ENTER**.



Record Speed	Video/Audio Quality	Record Time
HQ (High Quality)	Highest	1 Hour Max
SP (Standard Play)	Excellent	2 Hours Max
LP (Long Play)	Very Good	3 Hours Max
EP (Extended Play)	Better than VHS	4 Hours Max
SLP (Super Long Play)	Equal to VHS	6 Hours Max


- 3 Press **SETUP** to exit and save your changes.

Setting the Auto Chapter Option

You can set the recorder to automatically add a "chapter marker" every 5 minutes during your recordings. During playback, this will allow you to skip forward or back in 5 minute intervals by using the **NEXT/PREVIOUS** keys on the remote. These chapter markers are compatible with most standard DVD Players as well.

You can also add chapter markers manually. This procedure is covered in **EDITING YOUR RECORDINGS**.

- 1 Press **SETUP** and navigate with the **DOWN** key to the **RECORDING** menu. Press **ENTER**. Then, navigate to the **AUTO CHAPTER** menu and press **ENTER**.




- 2 Select an **Auto Chapter** option with the **UP/DOWN** keys and press **ENTER** to confirm. Press **SETUP** to exit and save changes.


Checking the Time and Date

Before you begin recording, you should make sure the Time and Date are both correct. The Time and Date are used not only to schedule recordings, but also to label recordings that you make live.

- 1 Press **SETUP** and navigate with the **DOWN** key to the **SYSTEM INFO** menu. Press **ENTER**. Then, press **ENTER** again to select **DATE AND TIME**.



- 2 Use the **UP/DOWN** keys to increase or decrease the **Time/Date** value, and the **LEFT/RIGHT** keys to move to a different field. Press **ENTER** to save your changes.



- 3 Press **SETUP** to exit the **SETUP MENU**.

TV Tuner Setup

Choose Cable or Antenna

It's important that this option is set correctly before scanning for available channels.

- 1 Press **SETUP** and navigate with the **DOWN** key to the **VIDEO SETUP** menu. Press **ENTER**. Then, navigate to the **CABLE/ANTENNA** option and press **ENTER**.

SETUP Language Video Setup Audio Setup System Info Disc Media Recording Schedule	VIDEO SETUP Aspect Ratio Channel Search Add/Del Channel Cable/Antenna Set Top Box Video Output Output Format	CABLE/ANT Antenna Cable
--	--	--------------------------------------

- 2 Select **ANTENNA** or **CABLE** and press **ENTER** to confirm.

Scanning for Available Channels

During the Initial Setup, the built-in TV Tuner scanned for available and added these to the channel list. However, if you have switched your input to Cable or Antenna, or moved to a different location, you may wish to perform the channel search again to refresh the store channel list.

- 1 Press **SETUP** and navigate with the **DOWN** key to the **SYSTEM SETUP** menu. Press **ENTER**. Then, navigate to the **CHANNEL SEARCH** option and press **ENTER**.

SETUP Language Video Setup Audio Setup System Setup Disc Media Record Mode Timer Record	SYSTEM SETUP Channel Search Add/Del Channel Cable/Antenna Date and Time Version Parental Level Password
---	---

- 2 Press **ENTER** to select **CONFIRM**. The TV Tuner now scans for available channels.

SETUP Language Video Setup Audio Setup System Setup Disc Media Record Mode Timer Record	CH SEARCH Confirm Cancel
---	---------------------------------------

- 3 When the process is completed, press **LEFT** to exit.

SETUP Language Video Setup Audio Setup System Setup Disc Media Record Mode Timer Record	Please wait.... Channels searching done! To exit press LEFT key.
---	--


Adding and Deleting Channels

After scanning for channels, the TV Tuner holds a list of available channels that are accessible with the **CH+** and **CH-** keys. You can manually edit this list by adding or deleting channels in the DVD Recorder's **SETUP MENU**.

- 1 Press **SETUP** and navigate with the **DOWN** key to the **SYSTEM SETUP** menu. Press **ENTER**. Then, navigate to the **ADD/DEL CHANNEL** option and press **ENTER**.

SETUP Language Video Setup Audio Setup System Setup Disc Media Record Mode Timer Record	SYSTEM SETUP Channel Search Add/Del Channel Cable/Antenna Date and Time Version Parental Level Password
---	---


- 2 Use the **UP/DOWN** keys to navigate to the channel you wish to Add or Delete. To access the next page of channels, press the **RIGHT** arrow key.



- 3 Press **ENTER** to toggle between **ADD** and **DELETE**. Press the **LEFT** key to exit the menu.

The Title Screen

When you insert a DVD+RW or DVD+R disc, the Title Screen will appear. The Title Screen displays thumbnail images and information for each title (recording) on the disc, as well as the amount of free space available for recordings.



- 1 THUMBNAIL IMAGE** - An image taken from the first frame of the recording, the thumbnail image provides a visual cue to help you identify the titles on the disc. You can replace this image with any frame from the recording - See **EDITING YOUR RECORDINGS**.
- 2 TITLE INFORMATION** - Displays information about the recording, including the Date and Time that the recording was made, the Input Source used, the total length of the recording and the Record Speed.
- 3 FREE SPACE** - This is the percentage of the total disc space that is available for recordings.
- 4 NEXT/PREVIOUS INDICATOR** - The **ARROW SYMBOL** appears above or below the 3 titles, indicating that a previous or next page of titles exists.

Types of Recordings

There are two recording methods you can use:

LIVE RECORDING - You start a live recording by simply pressing the **REC** button while viewing video from an input source, such as the TV Tuner or AV Inputs. You control the length of a live recording by pressing **REC** multiple times for 30 minute intervals or by pressing **STOP** to end the recording. A live recording will end automatically if the disc is full.

TIMER RECORDING - You can also schedule a recording to automatically begin at a particular Date and Time using the DVD Recorder's built-in **TIMER** function. Recordings can be scheduled to re-occur once a week or daily. The DVD Recorder must be in **STANDBY MODE** in order for a scheduled Timer Recording to begin.

Automatically Adding Chapter Markers

You can set the recorder to automatically add a **CHAPTER MARKER** every 5 minutes during your recordings. During playback, this will allow you to skip forward or back in 5 minute intervals by using the **NEXT/PREVIOUS** keys on the remote. These chapter markers are compatible with most standard DVD Players as well.

You can also add chapter markers manually. This procedure is covered in **EDITING YOUR RECORDINGS**.

Making a Live Recording

Selecting the Input Source

After a DVD+RW or DVD+R disc is inserted in the DVD Recorder, you must select the input source that will be recorded. You may choose from the following input sources:


TV - The DVD Recorder's built-in TV Tuner allows you to record your favorite TV programs.

VIDEO IN 1 - The Composite Video Input located at the back of the unit. Used for any video device with Composite Video Out.

S-VIDEO IN 1 - Located on the back panel, S-VIDEO provides a better picture than standard Composite Video. Use this input for camcorders or other video devices when possible.


VIDEO IN 2 - The Composite Video Input on the Front Panel.

S-VIDEO IN 2 - The Front Panel S-Video input.




- 1** To select the Input Source for recording, first press the **DVD/TV LIVE** button to switch to Recording Input Mode.
- 2** Next, bring up the Input Source menu using the **SOURCE** button.

- Use the UP/DOWN ARROW keys to select an Input Source, and press ENTER.




Recording

In Live Recording mode, you may record with no specific end point, or specify the length of the recording - in multiples of 30 minutes - using the REC button.



- To begin recording, press the REC button. This will begin recording without a specific end time. Alternatively, you can set the end time of the recording by pressing REC multiple times to cycle through 30 minute intervals. The stop time options will be dependent on the amount of disc space available, as well as the record mode (quality) setting.


If you wish to An icon will appear on the screen letting you know that the recording has begun. The DVD Recorder's front display will show "REC", followed by the elapsed time of the recording.



- You may pause the DVD Recorder during a Live Recording. Simply press PAUSE and the recording will stop temporarily. Press PAUSE again to resume recording.

- To end recording, press STOP. Keep in mind that the recording will end automatically if the disc runs out of space. There will be a pause while the player updates the disc contents.

- To return to the Title Screen, press TITLE. You will see a thumbnail image representing your last recording, with information on the details of the recording, including the Date and Time the recording was made, along with the Length and Recording Mode.




! Recording Over Existing Titles

Normally, a live recording is made with the Recorder in TV LIVE mode and an Input Video Source (such as the TV Tuner or AV Input) being viewed. In this scenario, a new title is created for the recording and existing titles are preserved.

Alternatively, you can choose to OVERWRITE existing recordings on a disc. To do this, press the REC key while the Recorder is in DVD playback mode. The Recorder will switch to TV Live mode. Now, press REC again. Using this method, the playback location or title selection will determine where the recording will begin and which titles will be overwritten.

Overwriting from a Playback Point

During playback of a recording, press REC, then REC again to begin overwriting existing titles from that point. In FIGURE 1 shown below, the recorder is in playback mode. Once REC is pressed, the player switches to TV LIVE mode, as shown in FIGURE 2. In FIGURE 3, the remainder of the original title will be overwritten with a new title by pressing REC again. Existing titles will also be overwritten depending on the length of the recording.



Selecting Titles to Overwrite

You can select titles to overwrite by pressing REC from the Title Screen. In the example below, the recorder is in DVD mode with the Title Screen displayed and **TITLE 2** selected. When the recording is started from this location by pressing REC *twice*, a new title will replace **TITLE 2** - and **TITLE 3** if the recording is of sufficient length. **TITLE 1** will be preserved because of its position *in front* of the title that was selected when REC was pressed.

1 CH 44
8:00:00 PM, Jan 2, 2003
Length: 0:30:00 Quality: HQ

2 CH 36
6:00:00 PM, Jan 3 2003
Length: 0:30:00 Quality: HQ

3 CH 44
6:00:00 PM, Jan 5 2003
Length: 0:60:00 Quality: HQ

OVERWRITE

! DVD+R Discs must be FINALIZED

Remember, your recording is not complete on a DVD+R disc until the disc is **FINALIZED**. Until a DVD+R disc is finalized, it can be recorded to, played back and edited on the DVD Recorder, but it will not be compatible with any other DVD Player. Finalization makes the disc compatible for playback on standard DVD Players. Once a disc is finalized, no more recordings can be added.


For more on Finalization, see **EDITING YOUR RECORDINGS**.

! Title Limit

A DVD+R/RW disc may contain up to 48 titles. Attempting to add additional title after this limit has been reached will result in an error.

Timer Recordings

You can use the Timer function to schedule recordings to begin and end at specific times. Timer Recordings are designed for unattended operation, and will only work when the recorder is in Standby Mode. During a Timer Recording, the recorder may not be used for any other operations.



- 1 To begin programming a scheduled recording, press the **TIMER** button on the remote control or front panel. This will access the recorder's built-in Timer Setup Screen, where you can program up to 8 scheduled recordings.

1	2	3	4	5	6
Entry	Freq	Start	Length	Source	Speed
01	___/___/___	___:___:___	___:___:___	___	___
02	___/___/___	___:___:___	___:___:___	___	___
03	___/___/___	___:___:___	___:___:___	___	___
04	___/___/___	___:___:___	___:___:___	___	___
05	___/___/___	___:___:___	___:___:___	___	___
06	___/___/___	___:___:___	___:___:___	___	___
07	___/___/___	___:___:___	___:___:___	___	___
08	___/___/___	___:___:___	___:___:___	___	___

- 1 **ENTRY** - You can input up to 8 independent schedules for Timer Recordings.
- 2 **FREQ** - The frequency that the schedule will automatically repeat. The following options are available:
 - **SINGLE DATE (No Repeat):** The default setting is the current date. This setting will be cleared after the recording is finished, or an error occurs, and will not be repeated.
 - **MON-FRI:** The recording will take place each week day, Monday through Friday, but not on Saturday or Sunday.
 - **DAILY:** The recording is repeated every day.
 - **WEEKLY (MON, TUE, WED, THU, FRI, SAT, SUN):** The recording will take place once each week on the day specified.
- 3 **START** - The time that the recording will begin, in 24-hour time. In this format, 1:00PM is represented as 13:00, 2:00PM as 14:00, etc.
- 4 **LENGTH** - The length of the recording.
- 5 **SOURCE** - The Video Input Source that will be used for the recording: TV Tuner, Video 1, S-Video 1, Video 2, S-Video 2.
- 6 **SPEED** - The Recording Speed (Quality Mode): HQ, SP, LP, EP, SLP.

- 2** Use the UP/DOWN ARROW keys to select an entry and press ENTER.


Entry	Freq	Start	Length	Source	Speed
01	08/15/05	20:00	1:00	Ch 002	HP

- 3** Use the UP/DOWN ARROW keys to select option values, and the LEFT/RIGHT ARROW keys to move among the fields.

Entry	Freq	Start	Length	Source	Speed
01	08/15/05	20:00	1:00	Ch 002	HP

Mon-Fri
Daily
Weekly Mon
Weekly Tue
....

- 4** To input numeric values such as START/STOP TIME and SOURCE TV CHANNEL, use the NUMBER keys.



- 5** To save an entry, press ENTER. The recorder will return to the Timer Schedule Screen and the new entry will be shown in the list:

Entry	Freq	Start	Length	Source	Speed
01	Weekly Mon	20:00	1:00	Ch 036	HQ
02	___/___/___	..:..	..:..	_____	___
03	___/___/___	..:..	..:..	_____	___
04	___/___/___	..:..	..:..	_____	___
05	___/___/___	..:..	..:..	_____	___
06	___/___/___	..:..	..:..	_____	___
07	___/___/___	..:..	..:..	_____	___
08	___/___/___	..:..	..:..	_____	___

- 6** To exit the Timer Menu, press TIMER.

! Timer Recording Messages

SWITCH OFF FOR TIMER RECORDING

For a scheduled Timer Recording to begin, the system must be in **STANDBY MODE**. You cannot use the recorder for another purpose, for instance to watch TV, *and* make a Timer Recording at the same time. The only way a Timer Recording can begin, is if the unit is powered down, with the front Standby light ON.

When you schedule a Timer Recording, you will see the message “SWITCH OFF FOR TIMER RECORDING” appear on screen, reminding you to switch the unit to Standby Mode before the recording is set to begin. This message will also appear on screen **5 MINUTES** before a Timer Recording is set to begin. At this point, you must switch the unit to Standby Mode to allow the recording to begin.

SCHEDULING OVERLAPPED!

This message is letting you know that at least 2 entries have conflicting schedules, where the recording periods overlap. In this case, the Timer Recording that begins first will take precedence, cancelling any entries that occur within it's recording period.

EDITING YOUR RECORDINGS

Editing Overview

Your DVD Recorder's capabilities go far beyond simply recording in Live and Timer modes. A vast array of editing options are also available, allowing you to tailor your recordings to your own personal requirements.

You can divide your recordings into sections, or Chapters, that provide the user-friendly navigation made popular on motion picture DVDs. You can also choose to "edit out" or bring back sections of your recordings with the HIDE and SHOW CHAPTER functions. Entire titles can be erased, although the space cannot be reclaimed with DVD+R discs. You can also change the Index Picture for any title, using any frame from within the recording.


Lastly, to make your discs compatible for distribution to clients or friends, use the Make Compatible and Finalize options for DVD+RW and DVD+R discs, respectively. These functions assure that all your edits will be "locked in" and your discs will playback just as you wish - on most DVD players!

EDIT MENU Functions - Title Screen


Use the EDIT MENU to access available editing functions. The EDIT MENU can be accessed in the Title Screen, or during playback of a DVD+R/RW disc. The available editing functions will change depending on the type of disc and where the menu is accessed.

Access the EDIT MENU from the Title Screen for top level editing functions. These functions deal with the compatibility and playback of an entire disc, rather than with individual titles, which are edited during playback.


- 1 First bring up the Title Screen by pressing TITLE when the Recorder is in DVD mode.



- 2 Press EDIT to access the EDIT MENU.



- 3 To perform any of the above functions in the EDIT MENU, use the UP/DOWN ARROW keys to select a function and press ENTER to confirm.



Erase Title

Deletes the currently selected Title. The functionality of this option is different with DVD+R & DVD+RW discs. With DVD+RW discs, the title is erased and the disc space freed for use for subsequent recordings. When a title is erased on a DVD+R disc, however, the disc space cannot be reclaimed - the title is essentially "hidden" and the disc space still used.

Play Full Title

This option works in conjunction with HIDE CHAPTER, which is covered in the next section. After a chapter is "hidden", it will no longer be shown during normal playback. Therefore, to "un-hide" the chapter you will need to first begin playback of the title using this option, making all hidden chapters visible. During playback, the SHOW CHAPTER option is used to make a chapter visible during normal playback again.

Make Compatible

Used with DVD+RW discs only, this function makes your edits - such as hidden chapters - compatible with standard DVD players. Use this option before distributing any recordings that you have edited to clients or friends. Before a DVD+RW disc is made compatible, all edits will only be visible when the disc is used in the DVD Recorder.

You can use this option multiple times, moving a DVD+RW disc back and forth between the DVD Recorder and a standard DVD player. Each time a disc is edited, it must be made compatible again.

Finalize


This option is only used with DVD+R discs - which **must** be FINALIZED before being used in a standard DVD player. Unlike DVD+RW discs, DVD+R discs cannot be moved back and forth between the recorder and standard players. You must finish all recordings on a DVD+R and finalize the disc before it will be usable on any other player.

Once a DVD+R disc is finalized, no further recordings can be made on the disc, and no edits can be performed.

Edit Title

By default, your recordings are named according to the Input Source used. You can change the name of a title using the EDIT TITLE function.


- 1 Use the UP/DOWN ARROW keys to select the EDIT TITLE option and press ENTER.



- 2 Use the UP/DOWN ARROW keys to select a Letter or Punctuation, and the LEFT/RIGHT keys to move to the previous/next character. Press ENTER to save.

EDIT MENU Functions - Playback

Access the EDIT MENU in playback mode to edit individual titles. The edits you make using the EDIT MENU will be immediate while the disc is used with the DVD Recorder. However, to make your edits compatible with other players, you must perform either the **Make Compatible** (DVD+RW) or **Finalize** (DVD+R) functions.




Insert Chapter



Chapters are a familiar feature on DVD discs. They provide a convenient way to navigate to a particular scene by dividing the disc into sections. Your DVD Recorder can be set to automatically add Chapter Markers to your recordings every 5 minutes in the SETUP MENU. Alternatively, you can add your own Chapter Markers, dividing a title into sections that you specify according to your requirements.

Once Chapter Markings are added to your recording and the disc is made compatible (DVD+RW) or Finalized (DVD+R), you will be able to use the PREVIOUS and NEXT buttons to move backward or forward through the chapters on any standard DVD Player.


- 1 During playback, press EDIT to access the EDIT MENU.



- 2 In the example shown below, the title already contains 2 chapters. To insert a Chapter Marker between chapters 1 and 2, press ENTER on the INSERT CHAPTER option of the EDIT MENU at the point you wish the new chapter to begin.



- 3 The new Chapter Marker will now become Chapter 2, and the existing chapter marker will move to Chapter 3. The title now contains 3 chapters.



! Chapter Markers Only are Added

Remember that when you add a CHAPTER, you are merely adding an additional CHAPTER MARKER to the title that is used for navigation. The actual video contained in the recording is never changed.

! Chapter Limit

Each title can have a maximum of 99 chapters, with a maximum 124 chapters allowed on a disc. Attempting to add additional chapters after this limit has been reached will result in an error.


Remove Chapter

You can delete chapter markers, making one longer chapter out of two. Removing a Chapter Marker is basically like adding a chapter, but in reverse. In the example below, the title contains 3 chapters.

- 1 During playback, press **EDIT** to access the **EDIT MENU**. Use the **DOWN Arrow Key** to select **REMOVE CHAPTER**.

EDIT
Insert chapter
Remove chapter
Hide chapter
Show chapter
New picture


- 2 In the example shown below, the title contains 3 chapters. Let's remove Chapter 2's marker by pressing **ENTER** during playback at any point within Chapter 2.



EDIT
Insert chapter
Remove chapter
Hide chapter
Show chapter
New picture



- 3 The title now has only 2 chapters. Chapter 1 consists of the original Chapter 1 and 2, while the original Chapter 3 is now the 2nd chapter in the title.



! Chapter Markers Only are Removed

The **REMOVE CHAPTER** function removes only the **MARKERS** for chapters, **NOT** the actual video contained in a chapter. To actually remove a section of video from a recording, use **HIDE CHAPTER**, which is covered in the next section.


Hide Chapter

If you wish to “edit out” a chapter from a recording, use the **HIDE CHAPTER** function.


If the segment of video you wish to remove is not already defined as a chapter, you must first add Chapter Markers at the **beginning** and **end** of the section, then use the **HIDE CHAPTER** function to remove the new chapter.

After a chapter is hidden, it will be invisible during playback as if it did not exist on the disc, even though it is still using space on the disc.

- 1 In this example, the section to be removed has not yet been defined as a chapter. In this case, first add Chapter Markers - following the procedures already covered - at the beginning and end of the section.




- 2 To **HIDE** the newly created chapter, playback the title. Press **EDIT** and select **HIDE CHAPTER**. At any point within the chapter you wish to remove, press **ENTER**.




EDIT
Insert chapter
Remove chapter
Hide chapter
Show chapter
New picture

- 3 The chapter will no longer be visible during playback of the title. To make the chapter playable again, use **SHOW CHAPTER**, covered in the next section.




Hiding Video Segments with the HIDE Button


You can hide video segments “on the fly” with the HIDE button. Recall that the HIDE CHAPTER function requires that a video segment be defined as a chapter first before it can be hidden. The HIDE button provides a shortcut to this method, by automatically creating chapters as you define the BEGINNING and END points of a video segment you wish to hide.




1 In this example, the title consists of only one chapter.



2 To mark the beginning of the video segment you wish to remove, press HIDE. The HIDE ICON appears on-screen, indicating that the current video will be hidden. Press HIDE again to mark the end of the segment. The HIDE ICON disappears from the screen.



3 The title now contains 3 chapters: Chapter 1 is the chapter *before* the hidden segment. Chapter 2 is the hidden segment we defined. Chapter 3 is the remaining video *after* the hidden segment. As with the HIDE CHAPTER option, you must select PLAY FULL TITLE from the TITLE EDIT MENU to view the hidden chapter.




Show Chapter


Recall from the previous section that when a chapter is HIDDEN and invisible during playback, it in fact still exists on the disc. The SHOW CHAPTER function provides a way to *reverse* HIDE CHAPTER, making previously hidden chapters viewable again.

! Use the Play Full Title Option

If you intend to make previously hidden chapters visible again, or simply view all hidden chapters, you must select the PLAY FULL TITLE option using the EDIT MENU from the TITLE SCREEN. This will play ALL chapters in the title, including hidden chapters.



1 During playback with the PLAY FULL TITLE option, hidden chapters will be identified by a message on the top right hand corner of the screen.




2 To make the chapter visible again, simply press EDIT and select SHOW CHAPTER. At ANY POINT within the hidden chapter, press ENTER.




New Picture

The Index Screen shows a thumbnail image representing each title on the disc. By default, this image is taken from the first frame of the recording. However, you may change this image to that of any frame contained in the title using the NEW PICTURE function.


INDEX PICTURE



- 1 Press PAUSE to freeze playback on the frame you wish to use as the new Index Picture.




- 2 Press EDIT to bring up the EDIT MENU. Use the DOWN ARROW key to select NEW PICTURE and press ENTER.





- 3 Press EDIT to exit the EDIT MENU. The Index Picture is now changed.

INDEX PICTURE CHANGED




Erasing a DVD+RW Disc


DVD+RW discs can be erased, deleting all content on the disc and freeing up all space for new recordings. You must enter the SETUP MENU to erase a DVD+RW disc.




- 1 Press SETUP to enter the SETUP MENU.



- 2 Use the DOWN key to navigate to the DISC MEDIA menu and press ENTER.




- 3 Press ENTER to select ERASE, and ENTER again to confirm.




THE DVD RECORDER SETUP MENU

Using the SETUP MENU


The DVD Recorder's SETUP MENU is where various settings are configured, including Recording Options, Playback Options, Languages, Parental Control Settings and more.



- 1 Press **SETUP** to enter the **SETUP MENU**. Use the **UP/DOWN ARROW** keys to select a sub-menu and press **ENTER**.



- 2 Use the **UP/DOWN ARROW** keys to select the option you wish to change and press **ENTER**.



- 3 Select the new value with the **UP/DOWN ARROW** keys and press **ENTER** to confirm.



- 4 To **EXIT** the **SETUP MENU**, press **SETUP**. Your changes will be saved.

Language Settings

SETUP

Language
Video Setup
Audio Setup
System Setup
Disc Media
Record Mode
Timer Record

LANGUAGE

OSD
DVD Menu
Audio
Subtitles

OSD

Default setting: **ENGLISH**

Sets the language used by the **SETUP MENU** and **ON-SCREEN DISPLAY**. **ENGLISH** (Default) and **SPANISH** are supported.

DVD MENU

Default setting: **ENGLISH**

Sets the default language used by DVD Menus. As an example, if a DVD disc contains multiple menu languages, such as Spanish and English, and this setting is set to **SPANISH**, then the Spanish menu will be used. Of course, the DVD must support multiple menu languages for this setting to work. Choices are: **ENGLISH, SPANISH, GERMAN, ITALIAN, FRENCH, CHINESE, ORIGINAL** (Default on DVD), **USER-DEFINED** (With specific Code).

AUDIO

Default setting: **ENGLISH**

Sets the default audio track used by DVDs. For example, if a DVD disc contains multiple audio tracks, such as Spanish and English, and this setting is set to **SPANISH**, then the Spanish audio track will play as the default. Of course, the DVD must support multiple menu languages for this setting to work. Choices are: **ENGLISH, SPANISH, GERMAN, ITALIAN, FRENCH, CHINESE, ORIGINAL** (Default on DVD), **USER-DEFINED** (With specific Code).

SUBTITLES

Default setting: **ON**

Sets the default subtitle language used by DVDs. For example, if a DVD disc supports multiple subtitle languages, such as Spanish and English, and this setting is set to **SPANISH**, then Spanish subtitles will be displayed by default. Of course, the DVD must support the language selected for this setting to work. Choices are: **ENGLISH, SPANISH, GERMAN, ITALIAN, FRENCH, CHINESE, ORIGINAL** (Default on DVD), **USER-DEFINED** (With specific Code).

Video Setup

SETUP

Language
Video Setup
Audio Setup
System Setup
Disc Media
Record Mode
Timer Record

VIDEO SETUP

Aspect Ratio
Video Output
Output Format

ASPECT RATIO

Default setting: **4:3 PanScan**

You can setup your DVD Player to work with normal and wide screen televisions. If you are using a wide screen TV, set this option to **16:9 WIDE** to match the aspect ratio of your TV. When used with a normal TV (4:3 aspect ratio), the **4:3 PANSKAN** setting results in the typical “Pan & Scan” display, where a movie is clipped on the sides to fit into the TV screen. The **4:3 LETTERBOX** setting will enable the “Letterbox” format, where the movie is presented in wide screen format with black lines at the top and bottom of the screen. The **4:3 PANSKAN** and **4:3 LETTERBOX** settings usually will have no effect, since very few movies support both options. DVDs are generally recorded with either PS or LB and do not allow switching between the two. So, viewing a widescreen DVD on a standard TV will result in black bars on the top and bottom of the screen.

VIDEO OUTPUT

Default setting: **COMPOSITE**

- **COMPOSITE:** Composite Video is supported on the majority of televisions. It is identified by a yellow-colored phono-type jack.
- **S-VIDEO:** A higher quality picture than standard COMPOSITE VIDEO, S-VIDEO requires a special cable (not included).
- **COMPONENT:** This setting is used for TVs supporting component video out and progressive scan. To activate the component video outputs, you must first connect the unit using the COMPOSITE VIDEO connector and cable in order to enter SETUP and change this setting. Next, connect the unit using the COMPONENT VIDEO cables and unplug the COMPOSITE video cable. Adjust the TV's Video Input setting to correspond to the COMPONENT Input.

OUTPUT FORMAT

Default setting: **NTSC**

Your DVD Player will work with TVs based on the NTSC and PAL standards, as well as TVs designed to function with both standards, or “Multi” models. NTSC is the standard TV system used in the USA, Canada, Japan and many other countries. The PAL TV system is used in Europe, Africa and the Middle East, among other places. Refer to your TV's documentation to make sure which model you have.

Most TVs scan only half the lines of an image in one pass. This scanning method is known as “interlaced” mode, as the odd and even lines are interlaced together in alternate scans, and is the default setting with the **NTSC** and **PAL** options. Progressive scan, set with the **PROGRESSIVE** option, is a scanning method offered on high-end TVs. Progressive scan TVs scan all the lines of an image in one pass, creating a more film-like quality to DVD movies. Note: All progressive scan TVs require component video inputs.

! Resetting the video output

If you inadvertently switch the **OUTPUT FORMAT** setting to **PROGRESSIVE** while using a standard TV not capable of **P-SCAN**, you will loose video. If this happens, reset the recorder to its default video settings by following these steps:

- 1) Power the unit Off, then On again with the main power switch on the back.
- 2) Eject the disc and close the disc tray.
- 3) Press and *hold* the **STOP** button on the front panel for 3 full seconds.

Audio Setup Options

SETUP

Language
Video Setup
Audio Setup
System Setup
Disc Media
Record Mode
Timer Record

AUDIO SETUP

Audio Output
SPDIF

AUDIO OUTPUT

Default setting: **LR STEREO**

This setting controls the audio output to the L/R stereo output connectors. Generally, this setting would not be changed, unless you plan to use the unit with a **MONO** audio device, in which case both stereo channels will be output through each jack.

SPDIF

Default setting: **SPDIF / RAW**

SPDIF (Sony/Philips Digital InterFace) refers to the digital audio format used by most consumer electronics equipment, as well as the Coaxial and Optical Digital Audio Output connectors on this unit. If you are using only the Stereo Audio Outputs, this setting is not applicable. The **DIGITAL** setting is used with receivers capable of Dolby Digital 5.1 or DTS 5.1 channel decoding, while the **PCM** setting is usually reserved for two channel equipment.

System Setup

SETUP	SYSTEM SETUP
Language	Channel Search
Video Setup	Add/Del Channel
Audio Setup	Cable/Antenna
System Setup	Date and Time
Disc Media	Version
Record Mode	Parental Level
Timer Record	Password
	Factory Reset
	Screen Saver
	Auto Shutdown

CHANNEL SEARCH

Default setting: **CONFIRM**

Confirm the Channel Search to automatically scan for available channels. The unit saves those channels received at sufficient signal strength. To cancel Channel Search, choose **CANCEL**.

ADD/DEL CHs

Allows you to manually add or delete channels from the tuner's channel list. Press the RIGHT ARROW key for subsequent pages of channel choices.

CABLE/ANT

Default setting: **ANTENNA**

Choose your TV connection. The default is **ANTENNA**, used with a typical air antenna receiving local stations. If you are using a Cable TV provider, choose **CABLE**.

DATE AND TIME

Set the Date and Time used by the unit for Timer Recording purposes. Use the UP/DOWN ARROW keys to increase or decrease the Date/Time values and LEFT/RIGHT ARROW keys to move to a different field. Press ENTER to confirm and save.

VERSION

Displays information about the unit's Firmware and Hardware versions. This information may be asked for by Tech Support for trouble-shooting purposes.

PARENTAL LEVEL

Default setting: **NO LIMIT**

The Parental Level allows you to limit the use of your DVD Player to only those DVD discs that do not exceed the rating you specify. Choices include **G, PG, PG-13, R, NC-17** and **NO LIMIT** (All discs play). When the parental level is set, DVD discs that support Parental Control will play only after the correct password has been entered. Non-supporting discs, however, will be "immune" to lockout.

The FIRST TIME you attempt to change the parental level setting, you are prompted to setup a password. After this, you will be prompted to enter the password you created in order to change the parental level. For more info, see **PASSWORD**, covered next.

PASSWORD

You must setup a **PASSWORD** to use the Parental Level options. When you FIRST attempt to use the Parental Control, you are prompted to create a **NEW PASSWORD**. Choose any 5-Digit number for your password and press ENTER. Enter the password again to confirm.

After your password is setup, use the **PASSWORD** menu option to change your existing password. You will be prompted to enter the **OLD** password, then the **NEW** password twice to confirm. If you should forget your password, you may use the **MASTER PASSWORD** of **98201** in place of the old password.

! Note on Parental Security

Remember to keep in mind that since the MASTER PASSWORD is listed above, your player may not be secure if this manual is accessible by your children.

FACTORY RESET

Default setting: **CONFIRM**

Use this option to **RESET** the unit to **FACTORY DEFAULTS**. All settings will be reset, including the **DATE** and **TIME**. All stored **CHANNELS** will be lost. Choose **CANCEL** to maintain your settings.

SCREEN SAVER

Default setting: **OFF**

You can enable the built-in **SCREEN SAVER**. When enabled by choosing **ON**, the Screen Saver will start if the unit remains paused for a period of about 5 minutes, protecting your TV from possible "screen burn" that could occur when a still image is displayed for too long.

AUTO SHUTDOWN

Default setting: **OFF**

With **AUTO SHUTDOWN** enabled, the unit will automatically go into **STANDBY** mode after a period of about 30 minutes of inactivity. Choose **ON** to enable. *This setting requires that the **SCREEN SAVER** be enabled.

Disc Media Options

SETUP

Language
Video Setup
Audio Setup
System Setup
Disc Media
Record Mode
Timer Record

DISC MEDIA

Finalize
Erase

FINALIZE

Default setting: **CONFIRM**

This option is only available when a DVD+R disc is being used. DVD+R discs must be FINALIZED before they will be playable in standard DVD Players. You must make all recordings on a disc BEFORE Finalization, since no more recordings can be added after this process. Choose **CONFIRM** to Finalize a disc, or **CANCEL** to abort.

ERASE

Default setting: **CONFIRM**

Available only with DVD+RW discs, use ERASE to completely clear all recordings from the disc. Choose **CONFIRM** to erase the disc's contents, or **CANCEL** to abort.

Record Mode Options

SETUP

Language
Video Setup
Audio Setup
System Setup
Disc Media
Record Mode
Timer Record

RECORD MODE

Record Quality
Auto Chapter

RECORD QUALITY

Default setting: **HQ**

Sets the QUALITY mode for recording. The default setting of **HQ** - HIGH QUALITY - is the highest quality setting, resulting in the best Video and Audio quality, but the shortest maximum recording time. You can choose from a variety of modes, each offering slightly less Video and Audio quality, but more maximum recording time: **SP, LP, EP, SLP**. For more on the RECORD QUALITY setting, see the RECORDING chapter.

AUTO CHAPTER

Default setting: **OFF**

You can set the unit to automatically add a CHAPTER MARKER approximately every 5 minutes during your recordings by changing this setting to **ON**. Chapter Markers make your recordings more usable by providing a way to skip to next or previous video segments. Alternatively, you may manually create your own Chapter Markers - see EDITING YOUR RECORDINGS.

Timer Record

Entry	Freq	Start	Length	Source	Speed
01	Weekly Mon	20:00	1:00	Ch 036	HQ
02	/ / /	:	:		
03	/ / /	:	:		
04	/ / /	:	:		
05	/ / /	:	:		
06	/ / /	:	:		
07	/ / /	:	:		
08	/ / /	:	:		

SETUP

Language
Video S
Audio S
System

Disc Media
Record Mode
Timer Record

The TIMER RECORD screen allows you to setup 8 scheduled recordings. You can choose the **FREQ** (when the recordings take place), the **START** time and **LENGTH**, the **SOURCE** used, and the **SPEED**, or quality mode. For more on setting up Timer Recordings, see the RECORDING chapter.

TROUBLESHOOTING

Common Problems & Solutions

Playback

The DVD Recorder Does Not Power On

- The AC Power cord may be loose or not plugged in. Make sure the power cord is secure in the AC socket and the connector on the back of the player.
- The unit may be in Standby Mode. Turn the player on with the remote POWER button, or turn the unit off with the back power switch, wait for a few seconds, then turn the unit back on.
- There must be a pause between powering the unit down and back on of a few seconds.

A Specific Disc Does Not Play

- The disc may be dirty. Try cleaning the disc.
- Make sure the disc is not in upside-down
- The REGION CODE of the disc may not match that of the player. In this case, the disc cannot be used.

The Remote Control Does Not Function

- Make sure you're aiming the remote directly at the player's remote sensor, located in the front display.
- Make sure there are no obstacles between the remote and the player.
- The batteries may be drained. Try changing the batteries in the remote.
- You could be using the remote too far away. Try within 4 meters of the player.

There is No Picture on the TV Screen

- Make sure the connections from the player to the TV are secure.
- Verify that the TV's channel is set to match the video input you're using. Refer to the TV's documentation.
- On most TVs the "Aux In", "Video In" or "A/V In" channel should match the video input connector.
- If you're using the S-Video connector, the TV may have a separate input channel for this type.

The Picture Appears Stretched or Squeezed

- The Video Aspect Ratio may be set wrong for your Television type.
- Enter the SETUP MENU and select the VIDEO OUTPUT MENU. Try changing the ASPECT setting to 4:3 PanScan (Pan & Scan) if you are using a standard TV, or 16:9 Wide if your TV is a Wide-Screen type.

The Disc Doesn't Eject

- If the player is in Standby Mode with the glowing LED to the left of the disc tray, the disc will not eject. Turn the player on with the Remote Control and then eject the disc.

Distorted Picture when Connected to a VCR

- This DVD Player is built with Macrovision copy-protection. This will distort the signal when used with VCRs. Connect the player directly to the TV.

Recording

Recording Will Not Start

- The Video Input Source may be protected with MacroVision Copy Protection.
- The disc may already contain recordings of a different TV System type - PAL or NTSC. If the disc already contains a PAL recording, you cannot record from an NTSC source, and vice versa.
- The maximum number of titles - 48 - may have been reached.
- If the disc is a DVD+R, it may already be FINALIZED.

The Disc Cannot be Erased

- The disc is not a DVD+RW disc.
- The disc may be dirty. Try cleaning the disc.

Recordings Do Not Play on Other DVD Players

- If the disc is a DVD+R, make sure it has been FINALIZED.
- The DVD Player may not support DVD+R/RW discs.

Timer Recording Does Not Start.

- The Time/Date is invalid or conflicts with another schedule.
- The Time/Date settings of the Recorder are incorrect. Set the Time/Date in SETUP.
- The specified Video Input Source is unavailable.
- The disc is out of space.

Hidden Chapters Cannot be Edited.

- You must select PLAY FULL TITLE from the EDIT MENU in the Title Screen to have access to Hidden Chapters.

SPECIFICATIONS

DISC TYPES SUPPORTED

- DVD+RW Playback, Recording
- DVD+R Playback, Recording
- DVD-RW Playback
- DVD-R Playback
- DVD-Video Playback
- VCD/SVCD Playback
- CD-Audio Playback
- CD-R/RW Playback

RECORDING

- Media DVD+R, DVD+RW
- Diameter 12cm
- Capacity 4.7GB
- Recording Time Maximum 6 Hours (SLP Mode)
- TV Systems NTSC/PAL
- Digital Compression MPEG 2, MPEG 1
- Recording Types Live, Timer
- Max Simultaneous Timer Recordings 8
- Recording Features
Pause Record, Auto-Insert Chapter, Index Screen Navigator,
Auto-Hide Chapter, Multi Record Modes
- Editing Features
Erase Disc, Change Index Picture, Hide Chapter, Show
Chapter, Edit Title Name

PLAYBACK

- MP3 & JPG Navigator
- Fast Forward / Reverse to x60
- Slow Motion Playback
- Repeat Playback (Chapter/Title/Disc & A-B)
- Commercial Skip Function
- Zoom to x4 with Panning

VIDEO PERFORMANCE

- Resolution . . . 720x480 NTSC, 720x576 PAL in HQ Mode
- DA Converter 10-bit
- AD Converter 9-bit
- Video Outputs Composite, S-Video, Component
- Scanning Progressive Scan, Interlaced
- Laser 650nm

AUDIO PERFORMANCE

- DA Converter 24 bit
- AD Converter 24 bit
- DVD Linear Sound
48kHz Sampling 4Hz to 22kHz
96kHz Sampling 4Hz to 44kHz
Audio CD 4Hz to 20kHz
- Signal to Noise Ratio >90dB
- Audio Dynamic Range >90dB
- Harmonic Distortion < 0.001% (W.PEAK)

OUTPUT CONNECTIONS

- Component Video Out
Y 1.0Vp-p (75 Ohm), Negative Sync
Pb/Pr7Vp-p (75 Ohm)
- S-Video Out Mini DIN 4-Pin (75 Ohm)
- Composite Video Out One Pin Jack, 1Vp-p (75 Ohm)
- Coaxial Digital Out One Pin Jack, .5Vp-p (75 Ohm)
- Optical Digital Out Standard Optical Connector
- Analog Audio Out 2.0VRMS (470 Ohm)

INPUT CONNECTIONS

- S-Video In (Front/Rear) Mini DIN 4-Pin (75 Ohm)
- Composite Video In (Front/Rear) Cinch, 1Vp-p (75 Ohm)
- Stereo Audio In (Front/Rear) 1.2VRMS (47 Ohm)

PHYSICAL

- Operating Conditions 5°C to 35°C
- Power Supply AC 100V~230V, 50/60Hz
- Power Consumption 60W
- Dimensions 65mm x 429mm x 348mm (H x L x D)
- Weight 4.88kg

**Specifications subject to change without notice. Part#: 1500C*

INDEX

a-b repeat	19	make compatible	30
angles (multi-angle playback)	19	menu button	16
antenna	13	messages (recording)	29
audio button	20	mp3 files	22
audio outputs	13	mute button	20
audio settings	36		
auto insert chapter	24	number buttons	7
a/v inputs	14		
		overwriting titles	27
batteries	6		
back panel	10	parental level	37
		password	27
chapters		play full title	30
auto insert	24	power	15
remove	32	power cord	15
hide	32-33		
coaxial output	13	recording	23
commercial skip	17	record quality	24
component video	12	region code	5
composite video	11	remote control	
connections		preparing	6
antenna	13	buttons	7
audio outputs	13	using	6
recording inputs	14	repeat playback	18
TV	11-12	reset	
contents (package)	6	factory defaults	37
copy protection	23	video settings	12
c-skip button	17	rf modulator	11
discs	5	safety instructions	2
display button	18,20	scanning channels	25
display (VFD)	9	screen saver	17
dvd+r	23	setup menu	35-38
dvd+rw	23	skip ahead/back	17
		slow motion	18
editing recordings	30	specifications	40
enter button	7	standby power	15
erase		still picture	17
disc	34,38	stop	17
title	30	storing channels	25
		subtitles	20
fast forward	17	s-video	12
features	4		
finalize	30,38	table of contents	3
front panel	8	timer recordings	28
		troubleshooting	39
hide button	33	tv tuner setup	25
hide chapters	32-33		
insert chapter	31	video outputs	11-12
		video settings	36
jpg images	21		
language settings	35	zoom	19
live recording	26		